



energreen

## CONNECTION WIFI

Onduleur GOODWEE

Energreen S.A.

Avenue Franklin 5C  
1300 Wavre  
Belgique

Tél: +32 (0) 10 45 13 73  
Email: [wavre@energreen.be](mailto:wavre@energreen.be)

## Section 2. Wi-Fi Configuration


**Step 1.** Click "Wi-Fi Configuration" at login page or click Wi-Fi icon at homepage.

**Step 2.** Make sure inverter is power on and then click "Next".

**Step 3.** Click "Go into WLAN setting interface".

**Step 4.** Connect smart device to SolarWiFi\* and then return to Wi-Fi configuration page of SEMS Portal.

### Step 1



### Step 1



### Step 2



**Step 5.** Click "Next".

**Step 6.** Enter Wi-Fi network name and password accordingly and then click "Set". Please switch off DHCP first and input IP address if you want to change inverter's IP into a specific one.


**Step 7.** Confirm and then click "OK".

! It is strongly recommended that you change the password of your "Solar-WiFi\*" before or after the installation. The manufacturer will NOT be responsible for any of the privacy information leakage caused by using the default password of "Solar-WiFi\*". For how to change the password of "Solar-WiFi\*", please refer to "Section 3. More Information" of "Option 1. Web Configuration".


### Step 6



### Step 6



### Step 7



### Step 3



### Step 4



### Step 5



! You may click "Reconfigure" or follow instruction of "Configuration Help" if configuration failed.

